

CONTROL TECHNIQUES



UNIDRIVE M700 UNIDRIVE M701 UNIDRIVE M702

High Performance AC/Servo Drives

Quick Startup, Operation
and Maintenance Guide

DRIVE OBSESSED



WARNING! This document is a guide only. It does not provide safety information. Incorrect installation or operation of the drive could result in injury or equipment damage. Refer to the Unidrive M700/M701/M702 Control User Guide for essential safety information.

Power Wiring – Sizes 3 to 9A

Heatsink mounted braking resistor

A resistor has been especially designed to mount within the heatsink of the Unidrive M sizes 3, 4 & 5. The design of the resistor is such that no thermal protection circuit is required, as the device will fail safely under fault conditions. On Unidrive M sizes 3, 4 & 5 the software overload protection is set up at default for the designated heatsink mounted resistor. If an external brake resistor is used, a thermal overload device is required. NOTE: The heatsink mounted resistor is suitable for applications with a low level of regen energy only.



WARNING




For complete wiring and fusing instructions, refer to

the Unidrive M Power Installation guide.

*Thermal overload for braking resistor to protect against fire risk. This must be wired to interrupt the AC supply in the even of a fault. This is not required if the optional heatsink mounted braking resistor is used.




*Optional braking resistor
Common DC bus connections



Control Wiring – Unidrive M700/M701

Control connections



Minimum connections to run motor

- Programmable analog
- Programmable digital
- Non-programmable


The 0V terminals on the Safe Torque Off are not isolated from each other and the 0V common.

* The Safe Torque Off/drive enable terminal is a positive logic only input.

† Terminal 51 and 52 must be connected to an external 24 V power supply if backup is required (frame sizes 6-11E only).

Control Wiring – Unidrive M702

Control connections



Minimum connections to run motor

- Programmable digital
- Non-programmable


* The Safe Torque Off/drive enable terminal is a positive logic only input.

† Terminal 51 and 52 must be connected to an external 24V power supply if backup is required (frame sizes 6-11E only).

Encoder Wiring

Encoder connector 15-pin D-type as standard on Unidrive M700/M701/M702


Encoder shielding connected to drive 0V and encoder 0V



| Terminal | Induction | Servo / PM | |
|----------|--------------------------|------------------------|---------------------------|
| | AB Pr 03.038 = 0 | Endat Pr 03.038 = 8 | AB Servo Pr 03.038 = 3 |
| 1 | A | DATA | A |
| 2 | A\ | DATA\ | A\ |
| 3 | B | CLK | B |
| 4 | B\ | CLK\ | B\ |
| 5 | Z | Freeze | Z |
| 6 | Z\ | Freeze\ | Z\ |
| 7 | Asim Out | | U |
| 8 | Asim\ Out | | U\ |
| 9 | Bsim Out | | V |
| 10 | Bsim\ Out | | V\ |
| 11 | Zsim Out | | W |
| 12 | Zsim\ Out | | W\ |
| 13 | +V (power supply output) | | |
| 14 | 0V | | |
| 15 | Thermistor | | |

For further information see the Unidrive M700/M701/M702 Control User Guide.

Keypad & Display



By default, the keypad display is in "Status Mode" for viewing current drive conditions, and can be changed to "Parameter Mode" for viewing and editing drive configuration settings.

Status mode

When in status mode, the drive status message/alarm/trip code is displayed on the upper left corner of the upper line, i.e., "Ready", "Inhibit", "Trip". See the "Display Messages" topic for more details.

Parameter mode





When in parameter mode, drive functionality can be viewed or modified by using the keypad. The parameter number is displayed on the upper line of the display (ex, 00.010), the parameter description is displayed on the second line, and the parameter value is displayed on the right-hand side of the bottom line.

Viewing parameters

The parameter number format is S.MM.PPP, where S = slot number for option modules and built-in communications, MM = menu number (menus are groupings of common functions), and PPP = parameter number (parameters are specific drive functions). For example: Pr. 00.010 is menu 0, parameter 10. Note: Menu 0 contains the most common parameters used in a typical setup and is programmable.

Keypad & Display

Navigating menus and parameters


You can find any parameter value using the arrow buttons. The  and  buttons are used to navigate between the slots and menus. The  and  buttons are used to navigate between the parameters in a menu.

To edit/modify parameters

In order to change the value of a parameter, go to the parameter you would like to change and then press the enter button. Now the cursor shifts to the parameter value. You can increase the parameter value by pressing the up button or decrease the parameter value by pressing the down button. The right and left buttons can be used to switch between the digits within the parameter value. Pressing the enter button again will set the newly selected parameter value, and the cursor will return to the parameter number.

Note: Certain parameters are read only (RO) and cannot be changed. For example Pr. 0.11 – drive output frequency, cannot be changed. Pressing the return button will return the keypad to status.

To Save parameter values

Changes made to parameters will be lost when the drive is turned off unless parameters are saved. To save new parameter changes, enter 1001 into any Pr.MM.000 and then press the Stop/Reset  button.

To reset to USA (60 Hz) defaults

To reset the drive to USA default parameter settings, open the drive enable signal (Terminal 31), enter 1244 into Pr MM.000 and then press the Stop/Reset button. Save the parameter values by entering 1001 into Pr MM.000 and then pressing the Stop/Reset button.

Display Messages

Alarm indications

| Alarm string | Description |
|-------------------|--|
| Brake resistor | Brake resistor overload. Braking resistor thermal accumulator (10.039) in the drive has reached 75.0% of the value at which the drive will trip. |
| Motor overload | Motor protection accumulator (04.019) in the drive has reached 75.0% of the value at which the drive will trip and the load on the drive is >100%. |
| Inductor overload | Regen inductor overload. Inductor protection accumulator (04.019) in the drive has reached 75.0% of the value at which the drive will trip and the load on the drive is >100%. |
| Drive overload | Drive over temperature. Percentage of drive thermal trip level (07.036) in the drive is greater than 90%. |
| Autotune | The autotune procedure has been initialized and an autotune in progress. |
| Limit switch | Limit switch active. Indicates that a limit switch is active and that is causing the motor to be stopped. |

Status indications

| Display | Description |
|---------------|---|
| Inhibit | The drive is inhibited and cannot be run. |
| Ready | The drive is ready to run. |
| Stop | The drive is stopped/holding zero speed. |
| Run | The drive is active and running. |
| Trip | The drive has tripped and no longer controlling the motor. |
| Under voltage | The drive is in the under voltage state either in low voltage or high voltage mode. |




Trip codes

| Display | Description - troubleshooting tips |
|------------|---|
| Over volts | <ul style="list-style-type: none">• Increase deceleration ramp (Pr 00.004).• Decrease the braking resistor value (staying above the minimum value).• Check nominal AC supply level. |
| OI.AC | <ul style="list-style-type: none">• Acceleration/deceleration rate is too short.• If seen during auto-tune reduce the voltage boost.• Check for short circuit on the output cabling. |
| Encoder2 | <ul style="list-style-type: none">• Ensure that the position feedback device type selected in Pr 03.038 is correct for the position feedback device connected to the P1 interface on the drive.• If wire break detection on the drive encoder input is not required, set Pr 03.040 = XXX0 to disable the encoder 2 trip.• Check cable continuity.• Check wiring of feedback signals is correct.• Check encoder power supply is set correctly (Pr 03.036). |

For other display messages and trip codes with more recommended actions please refer to the Unidrive M700/M701/M702 Control User Guide or to the mobile Diagnostic Tool app.




Induction Motor Setup

Open loop

| Unidrive M70x open loop induction motor setup | | |
|---|--------------------------------------|--|
| Parameter description | Parameter | Comments |
| USA defaults | 00.000 = 1254 00.048 (11.031) = 1 | Drive USA defaults (60 Hz) (Open loop) mode |
| Reset the drive | RESET | Red button on keypad  |
| User security status | 00.049 (11.044) = 1 | All menus |
| Reference selector | 00.005 (01.014) = 4 (Keypad) | Keypad control |
| Reset the drive | RESET | Red button on keypad  |
| Max reference clamp | 00.002 (01.006) = | Motor nameplate value |
| Acceleration rate | 00.003 (02.011) = 5.0 | s/1000 rpm |
| Deceleration rate | 00.004 (02.021) = 10.0 | s/1000 rpm |
| Ramp mode | 00.015 (02.004) = Standard | "Fast" ramp if braking resistor installed. Also ensure Pr 10.030, Pr 10.031 & Pr 10.061 are set correctly. |
| Motor rated voltage | 00.044 (05.009) = | Motor nameplate value |
| Rated speed | 00.045 (05.008) = | Motor nameplate value |
| Motor rated current | 00.046 (05.007) = | Motor nameplate value |
| Motor rated frequency | 00.047 (05.006) = | Motor nameplate value |
| Save parameters to NVM | 00.000 = 1001 | |
| Reset the drive | RESET | Red button on keypad  |




Perform an autotune

Warning: A rotating autotune will cause the motor to accelerate up to 2/3 base speed in the direction selected regardless of the reference provided. Once complete the motor will coast to a stop. The enable signal must be removed before the drive can be made to run at the required reference.

| | | |
|---|-----------------------------|--|
| Autotune | 00.040 (05.012) = 2 | Motor loaded stationary autotune = 1 Motor unload/uncoupled autotune = 2 |
| Close drive Safe Torque Off signal(s) – M700/701: (jumper terminal 22 to terminal 31); M702: (jumper Terminals 2, 11, and 13) | | |
| Press keypad RUN (green) button  | | |
| ***** Wait for drive/motor to stop rotating and display "Ready" or "Inhibit" ***** | | |
| Save parameters to NVM | 00.000 = 1001 | |
| Reset the drive | RESET | Red button on keypad  |
| Open Drive Safe Torque Off signal(s) – M700/701: (remove jumper from T22 to T31); M702: (remove jumpers from T2, T11, and T13) | | |
| Save parameters to NVM | 00.000 = 1001 | |
| Reference selector | 00.005 (01.014) = 0 (AI A2) | Terminal strip control |
| Reset the drive | RESET | Red button on keypad  |




Induction Motor Setup

Closed loop

| Unidrive M70x closed loop induction motor setup | | |
|---|------------------------------|--|
| Parameter description | Parameter | Comments |
| USA defaults | 00.000 = 1254 | Drive USA defaults (60 Hz) |
| | 00.048 (11.031) = 2 (RFC-A) | Rotor Flux Control-Asynchronous |
| Reset drive | RESET | Red button on keypad |
| User security status | 00.049 (11.044) = 1 | (All menus) |
| Reference selector | 00.005 (01.014) = 4 (Keypad) | Keypad control  |
| Reset drive | RESET | Red button on keypad |
| Max reference clamp | 00.002 (01.006) = | Motor nameplate value |
| Acceleration rate | 00.003 (02.011) = 2.000 | s/1000 rpm  |
| Deceleration rate | 00.004 (02.021) = 2.000 | s/1000 rpm |
| Ramp mode | 00.015 (02.004) = Standard | "Fast" ramp if braking resistor installed. Also ensure Pr 10.030, Pr 10.031 & Pr 10.061 are set correctly. |
| Motor rated voltage | 00.044 (05.009) = | Motor nameplate value |
| Rated speed | 00.045 (05.008) = | Motor nameplate value |
| Motor rated current | 00.046 (05.007) = | Motor nameplate value |
| Motor rated frequency | 00.047 (05.006) = | Motor nameplate value |
| Drive encoder lines per rev | 03.034 = 1024 | Encoder technical information |
| Drive encoder supply voltage | 03.036 = 0 (5V) | Encoder technical information |
| Drive encoder type | 03.038 = 0 (AB) | Encoder setup |
| Save parameters to NVM | 00.000 = 1001 | |
| Reset drive | RESET | Red button on keypad  |





Perform an autotune

Warning: A rotating autotune will cause the motor to accelerate up to 2/3 base speed in the direction selected regardless of the reference provided. Once complete the motor will coast to a stop. The enable signal must be removed before the drive can be made to run at the required reference.

| | | |
|---|-----------------------------|--|
| Autotune | 00.040 (05.012) = 2 | Motor loaded stationary autotune = 1 Motor unload/uncoupled autotune = 2 |
| Close drive Safe Torque Off signal(s) – M700/701: (jumper terminal 22 to terminal 31); M702: (jumper Terminals 2, 11, and 13) | | |
| Press keypad RUN (green) button  | | |
| ***** Wait for drive/motor to stop rotating and display "Ready" or "Inhibit" ***** | | |
| Save parameters to NVM | 00.000 = 1001 | |
| Reset the drive | RESET | Red button on keypad  |
| Open Drive Safe Torque Off signal(s) – M700/701: (remove jumper from T22 to T31); M702: (remove jumpers from T2, T11, and T13) | | |
| Save parameters to NVM | 00.000 = 1001 | |
| Reference selector | 00.005 (01.014) = 0 (AI A2) | Terminal strip control |
| Reset the drive | RESET | Red button on keypad  |




Permanent Magnet Motor Setup

Closed loop





| Unidrive M70x closed loop permanent magnet motor setup | | |
|--|------------------------------|--|
| Parameter description | Parameter | Comments |
| USA defaults | 00.000 = 1254 | Drive USA defaults (60 Hz) |
| | 00.048 (11.031) = 3 (RFC-S) | Rotor Flux Control-Synchronous |
| Reset the drive | RESET | Red button on keypad  |
| User security status | 00.049 (11.044) = 1 | (All menus) |
| Reference selector | 00.005 (01.014) = 4 (Keypad) | Keypad control |
| Reset the drive | RESET | Red button on keypad  |
| Max reference clamp | 00.002 (01.006) = | Set to 1.2 x Pr 05.008 (rpm) |
| Acceleration rate | 00.003 (02.011) = 2.000 | s/1000 rpm |
| Deceleration rate | 00.004 (02.021) = 2.000 | s/1000 rpm |
| Ramp mode | 00.015 (02.004) = Standard | "Fast" ramp if braking resistor installed. Also ensure Pr 10.030, Pr 10.031 & Pr 10.061 are set correctly. |
| Catch a spinning motor | 00.033 (06.009) = 0 (Off) | |
| Max switching frequency | 00.041 (05.018) = | Motor nameplate value (min.Fsw) (kHz) |
| Number of motor poles | 00.042 (05.011) = | Motor nameplate value |
| Motor rated voltage | 00.044 (05.009) = | Motor nameplate value |
| Rated speed | 00.045 (05.008) = | Motor nameplate value |
| Motor rated current | 00.046 (05.007) = | Motor nameplate value |
| Volts per 1000 rpm | 00.047 (05.033) = | Motor nameplate value |
| Drive encoder lines per rev | 03.034 = 1024 (Lines) | Encoder technical info |
| Drive encoder supply voltage | 03.036 = 0 (5V) | Encoder technical info |
| Drive encoder type | 03.038 = 0 (AB servo) | 0 (AB servo) encoder technical info |
| Current reference filter | 04.012 = 0.2 ms | Current reference filter 1 time constant |
| High speed mode | 05.022 = -1 (Limit) | |
| Stop mode | 06.001 = 1 (Ramp) | No ramp is default |
| Hold zero speed | 06.008 = 0 (Off) | |
| Reset the drive | RESET | Red button on keypad  |
| Save parameters to NVM | 00.000 = 1001 | |
| Reset the drive | RESET | Red button on keypad  |




Perform an autotune

Warning: A rotating autotune will cause the motor to accelerate up to 2/3 base speed in the direction selected regardless of the reference provided. Once complete the motor will coast to a stop. The enable signal must be removed before the drive can be made to run at the required reference.

| | | |
|---|-----------------------------|--|
| Autotune | 00.040 (05.012) = 2 | Motor loaded stationary autotune = 1 Motor unload/uncoupled autotune = 2 |
| Close drive Safe Torque Off signal(s) – M700/701: (jumper terminal 22 to terminal 31); M702: (jumper Terminals 2, 11, and 13) | | |
| Press keypad RUN (green) button  | | |
| ***** Wait for drive/motor to stop rotating and display "Ready" or "Inhibit" ***** | | |
| Save parameters to NVM | 00.000 = 1001 | |
| Reset the drive | RESET | Red button on keypad  |
| Open Drive Safe Torque Off signal(s) – M700/701: (remove jumper from T22 to T31); M702: (remove jumpers from T2, T11, and T13) | | |
| Save parameters to NVM | 00.000 = 1001 | |
| Reference selector | 00.005 (01.014) = 0 (AI A2) | Terminal strip control |
| Reset the drive | RESET | Red button on keypad  |

Servo Motor Setup

| Unidrive M70x servo motor setup | | |
|---------------------------------|------------------------------|--|
| Parameter description | Parameter | Comments |
| USA defaults | 00.000 = 1254 | Drive USA defaults (60 Hz) |
| | 00.048 (11.031) = 3 (RFC-S) | Rotor Flux Control-Synchronous |
| | RESET | Red button on keypad  |
| User security status | 00.049 (11.044) = 1 | (All Menus) |
| Reference selector | 00.005 (01.014) = 4 (Keypad) | Keypad control |
| | RESET | Red button on keypad  |
| Max reference clamp | 00.002 (01.006) = | Motor nameplate value |
| Acceleration rate | 00.003 (02.011) = 0.200 | s/1000 rpm |
| Deceleration rate | 00.004 (02.021) = 0.200 | s/1000 rpm |
| Ramp mode | 00.015 (02.004) = Standard | "Fast" ramp if braking resistor installed. Also ensure Pr 10.030, Pr 10.031 & Pr 10.061 are set correctly. |
| Number of motor poles | 00.042 (05.011) = | Motor nameplate value |
| Motor rated voltage | 00.044 (05.009) = | Motor nameplate value |
| Rated speed | 00.045 (05.008) = | Motor nameplate value |
| Motor rated current | 00.046 (05.007) = | Motor nameplate value |
| Drive encoder lines per rev | 03.034 = | Encoder technical info |
| Drive encoder supply voltage | 03.036 = 0 (5V) | Encoder technical info |
| Drive encoder type | 03.038 = 8 (EnDat) | 8 (EnDat), 3 (AB Servo) |
| Encoder termination select | 03.039 = 1 | |
| Stop mode | 06.001 = 1 (Ramp) | No ramp is default |
| | RESET | Red button on keypad  |
| Save parameters to NVM | 00.000 = 1001 | |
| | RESET | Red button on keypad  |

| Perform an autotune | | |
|---|-----------------------------|--|
| <p>Warning: A rotating autotune will cause the motor to accelerate up to 2/3 base speed in the direction selected regardless of the reference provided. Once complete the motor will coast to a stop. The enable signal must be removed before the drive can be made to run at the required reference.</p> | | |
| Autotune | 00.040 (05.012) = 2 | Motor loaded stationary autotune = 1 Motor unload/uncoupled autotune = 2 |
| <p>Close drive Safe Torque Off signal(s) – M700/701: (jumper terminal 22 to terminal 31); M702: (jumper Terminals 2, 11, and 13)</p> | | |
| <p>Press keypad RUN (green) button </p> | | |
| <p>***** Wait for drive/motor to stop rotating and display "Ready" or "Inhibit" *****</p> | | |
| Save parameters to NVM | 00.000 = 1001 | |
| Reset the drive | RESET | Red button on keypad  |
| <p>Open Drive Safe Torque Off signal(s) – M700/701: (remove jumper from T22 to T31); M702: (remove jumpers from T2, T11, and T13)</p> | | |
| Save parameters to NVM | 00.000 = 1001 | |
| Reference selector | 00.005 (01.014) = 0 (AI A2) | Terminal strip control |
| Reset the drive | RESET | Red button on keypad  |

Universal Encoder Module

SI-UNI-ENCODER system integration module


This option provides an additional incremental or absolute encoder feedback port and simulated encoder output.



10-way
pluggable
connector



15-way
female D-type
connector



| Terminal | | Encoder | | |
|-------------------------|----------------------------|--------------------------|------------------------|---------------------------|
| 15 way D-type connector | 10 way pluggable connector | AB Pr 1x.038 = 1 | EnDat Pr 1x.038 = 4 | AB Servo Pr 1x.038 = 3 |
| 1 | | A | DATA | A |
| 2 | | A\ | DATA\ | A\ |
| 3 | | B | CLK | B |
| 4 | | B\ | CLK\ | B\ |
| 5 | | Z | Freeze | Z |
| 6 | | Z\ | Freeze\ | Z\ |
| 7 | 3 | Asim Out | | U |
| 8 | 4 | Asim\ Out | | U\ |
| 9 | 5 | Bsim Out | | V\ |
| 10 | 6 | Bsim\ Out | | V\ |
| 11 | 8 | Zsim Out | | W |
| 12 | 9 | Zsim\ Out | | W\ |
| 13 | 10 | +V (power supply output) | | |
| 14 | 2, 7 | 0V | | |
| 15 | | Thermistor | | |
| | 1 | +24 V freeze input | | |

For further information see the SI-Universal Encoder User Guide.

Expanded I/O

SI-I/O system integration module


This option increases the number of I/O points on a drive. All connections from the option module to the drive are made via the drive connector.



PL1



PL2



| PL1 | Function |
|-----|--------------------------------|
| T1 | 0V common |
| T2 | Digital input/output 1 |
| T3 | Digital input/output 2 |
| T4 | Digital input/output 3 |
| T5 | Digital input/output 4 |
| T6 | 0V common |
| T7 | Analog input 1/digital input 5 |
| T8 | Analog input 1/digital input 6 |
| T9 | Analog input 1/digital input 7 |
| T10 | 0V common |
| T11 | Analog input 1/digital input 8 |

11 way pluggable screw connector

| PL2 | Function |
|-----|--------------|
| T21 | Relay 1 |
| T22 | Relay common |
| T23 | Relay 2 |

3 way pluggable screw connector


For further information see the SI-I/O User Guide.

Unidrive M Connect commissioning tool

The Unidrive M700/M702 comes with built-in Ethernet. The Unidrive **M Connect** PC software can be used on a computer to access drive parameters once the following drive and computer adjustments have been made.

Slot 4 - drive configuration

| Parameter | Function |
|------------------------------|---------------------|
| Pr. 4.02.005 = Off | Disable DHCP |
| Pr. 4.02.006 = 192.168.1.100 | Set an IP address |
| Pr. 4.02.007 = 255.255.255.0 | Set the subnet |
| Pr. 4.00.007 = On | Enable new changes |
| Pr. s.mm.000 = '1001' | Save the parameters |



| LED Status | Description |
|----------------|--|
| Off | Ethernet connection not detected |
| Solid green | Ethernet connection detected but no data |
| Flashing green | Ethernet connection detected and data flow |

The Unidrive M701 comes with built-in RS485. The Unidrive **M Connect** PC software can be used on a computer to access drive parameters by connecting the computer to the drive using a CT-USB-CABLE (pictured below).



Smartcard

Parameter storage / cloning

The Smartcard is a memory device that can be used to back-up parameter sets and PLC programs, and copy them from one drive to another.



Pr 0.30 = rEAD + 

Drive reads all parameters from the Smartcard.



Pr 0.30 = Prog + 


Programs all drive parameters to the Smartcard.

Note: overwrites only data already in block 1.



Pr 0.30 = Auto + 

Drive automatically writes to the Smartcard when a parameter save is performed.



Pr 0.30 = boot + 

Drive boots from the Smartcard on power-up and automatically writes to the Smartcard when a parameter save is performed.

Notes

Support

24/7 technical support

- 1-800-893-2321
- CTdrives.com/techsupport



For manuals, application notes and information on our support services visit our website:
www.controltechniques.com



Control Techniques
7078 Shady Oak Road
Eden Prairie, MN 55344

The Nidec logo, featuring the word "Nidec" in a bold, italicized, green sans-serif font.